



INSTALLATION GUIDE

Step 1

Wipe off dust, dirt, or mold and clean the installation area prior to placing the material.



Step 2

Apply sealant with a brush or roller and wait 15 to 30 minutes for it to dry completely.



Step 3

Before cutting, measure the wall where the sheet will be placed. This will avoid liner panel surplus when cutting. Make sure that the panel's surface fits into the space to be installed before placing the adhesive.



Step 4

Cut sheet according to the surface's measurements. Leave 1 to 2 millimeters on each side for the dilation and natural expansion of the panel.



Step 5

Cut moldings according to the panel's measurements.



Step 6

Insert the molding in Glasliner's edges prior to placement.
 *If a union of two sheets is required, insert a dividing bar prior to installation.



Step 7

Apply adhesive to the back of the Liner Panel using a trowel. The adhesive must be placed in the same direction prior to placing the material.



Step 8

Install Glasliner on the surface.



Step 9

Press on the liner panel with a roller to remove any air that may remain between the adhesive and the wall.



Step 10

Wipe clean Glasliner's surface with a cloth and water and remove any remaining adhesive.

